

What temperature should I keep my thermostat set?

We recommend 78 degrees on cooling and 68 degrees in heating. Remember that for each degree below 78 degrees you will increase the energy cost for air conditioning by a significant amount.