

How do I know if my unit is not working properly?

Typically in Central Texas when the temperature is 92 degrees outside your A/C system should be able to maintain 78 degrees indoors and cycle on and off a couple of times per hour. Or when in your opinion it is not cooling or heating properly, or if the unit is making peculiar noise.