

How often should I hose out and clean the condenser coils?

We recommend twice a year cleaning, by a trained maintenance professionals. If you get water in the wrong place you could create serious damage to your equipment, you could even experience electrical shock if you are not careful.